


Light and easy chair

Gärtnäs

Design by Åke Axelsson, 2004
Article ID: 4594



Disassembly

The following components can easily be disassembled for repair, maintenance, or recycling:
Remove and replace the upholstery from the seat – the upholstery is mounted on a separate board that can be screwed off and on by hand or with a screwdriver, allowing it to be re-upholstered.
Remove and replace the plastic glides from the base.

Factory Disassembly

Disassembly of the wooden frame and replacement of the upholstery on the backrest should only be carried out at the Gärtnäs factory or by a certified service partner.