


Button armchair

Gärtnäs

Design by Pierre Sindre, 2008
Article ID: 4685



Disassembly

Remove and replace the plastic glides from the base.

Factory Disassembly

Disassembly of the wooden frame and replacement of the upholstery on the backrest and seat should only be carried out at the Gärtnäs factory or by a certified service partner.