


Day light chair

Gärtnäs

Design by Pierre Sindre, 2026
Article ID: 6295



Disassembly

The following components can easily be disassembled for repair, maintenance, or recycling:
The wooden base is mounted with four screws and can be replaced with a new one of the same type, or alternatively with a metal base with four legs or a metal swivel base with wheels. Wheels can easily be snapped off and changed. Remove and replace the plastic glides from the legs.

Factory Disassembly

N/A