
Ateljé table

Gärsnäs

Design by Matti Klenell, 2018
Article ID: 7310



Disassembly
The dining table can be extended or retracted using an additional extension leaf. To disassemble the table, first unscrew the frame lock located on the central beam. The tabletops can then be removed from the supporting frame using a screwdriver or power screwdriver. Finally, unscrew the extension mechanism beneath the tabletop, allowing the entire table to be separated into individual components for repair, replacement, or recycling.

Factory Disassembly
Disassembly of the wooden frame should only be carried out at the Gärsnäs factory or by a certified